


Hinge systems



- ▶ CLIP top BLUMOTION | CLIP top – hinges
- ▶▶ Angled application – standard



Hinge systems

+30° II – angled hinge overlay



- CLIP top BLUMOTION with integrated BLUMOTION (with deactivation option)
- CLIP top without closing mechanism (spring)
- All metal hinge
- +30° II angled hinge
- 95° opening angle
- 3-dimensional front adjustment
- Convenient spiral-tech depth adjustment
- Tool-free door to cabinet assembly and removal
- With INSERTA tool-free hinge to door assembly

Webcode
DQDTDA

Page instructions

WA	Angle		
	25°	30°	35°
	N° 20	N° 21	N° 22
	144	145	145
	N° 50	N° 51	N° 52
	144	145	145
	N° 5	N° 6	N° 7
	149	145	145
	N° 40	N° 41	N° 42
	146	146	146
	N° 57	N° 58	N° 59
	144	145	145
Overview – angled applications			136
WA Angled application			

Order information

Boss		INSERTA		Part no.
Hinge	Spring	Colour		
CLIP top		NI ONS		79B9596
BLUMOTION	●	NI	Nickel plated	
	○	ONS	Onyx black	

Boss		Screw-on		Part no.
Hinge	Spring	Colour		
CLIP top		NI		79B9556
BLUMOTION	●	NI		
CLIP top	○	NI		78A9556.T

a Accessories

Hinge arm cover cap		Part no.
Print Stamp	Logo	
Plain	–	NI ONS 70.1553
Screen print	Blum	NI 70.1553.BL

Hinge boss cover cap		Part no.
Hinge	Colour	
CLIP top	NI ONS	70T3504
BLUMOTION	NI ONS	70T3504
CLIP top	NI	70T1504

TIP-ON for doors		Part no.
Version	Spring	
Short version	○	956.1004
Extended version	○	956A1004
Extended version	●	956A1006

Chipboard screws		Part no.
Ø (mm)	Length (mm)	
3.5	15	609.1500
3.5	17	609.1700

Note

CLIP top BLUMOTION and CLIP top hinges cannot be combined with each other on a front.

Page instructions

Overview – CLIP top BLUMOTION CLIP top – hinges	93	Overview – TIP-ON for doors	199	Assembly, removal and adjustment
Mounting plates	172	Overview – assembly devices	595	
Accessories – hinge arm cover cap	181	More technical details	686	
Accessories – general	182			Short-URL www.blum.com/a210

Planning

Note

These dimensions are based on the factory setting. The application changes in cases of deviation. In these cases a trial is recommended. Some applications require the mounting plate to be moved from the standard fixing positions.

 N° 20 25° Dimensions: 85.5, 54.5, 47, 19, 11.4, 19, 36, 1, 5	 N° 50 25° Dimensions: 68, 37.5, 38, 19, 11, 1, 26.5, 5, 16	 N° 57 25° Dimensions: 66.5, 36, 35, 16, 11.4, 18, 1, 70°, 45°, 22.5, 9.5, 2.5, 16, 1, 5																											
<table border="1"> <thead> <tr> <th>Description</th> <th>Spacing (mm)</th> <th>Part no.</th> </tr> </thead> <tbody> <tr> <td>Mounting plate</td> <td>9</td> <td>175H7190</td> </tr> <tr> <td>Angled spacer</td> <td>-5°</td> <td>171A5500</td> </tr> </tbody> </table>	Description	Spacing (mm)	Part no.	Mounting plate	9	175H7190	Angled spacer	-5°	171A5500	<table border="1"> <thead> <tr> <th>Description</th> <th>Spacing (mm)</th> <th>Part no.</th> </tr> </thead> <tbody> <tr> <td>Mounting plate</td> <td>0</td> <td>173H7100</td> </tr> <tr> <td>Angled spacer</td> <td>-5°</td> <td>171A5500</td> </tr> </tbody> </table>	Description	Spacing (mm)	Part no.	Mounting plate	0	173H7100	Angled spacer	-5°	171A5500	<table border="1"> <thead> <tr> <th>Description</th> <th>Spacing (mm)</th> <th>Part no.</th> </tr> </thead> <tbody> <tr> <td>Mounting plate</td> <td>0</td> <td>173H7100</td> </tr> <tr> <td>Angled spacer</td> <td>-5°</td> <td>171A5500</td> </tr> </tbody> </table>	Description	Spacing (mm)	Part no.	Mounting plate	0	173H7100	Angled spacer	-5°	171A5500
Description	Spacing (mm)	Part no.																											
Mounting plate	9	175H7190																											
Angled spacer	-5°	171A5500																											
Description	Spacing (mm)	Part no.																											
Mounting plate	0	173H7100																											
Angled spacer	-5°	171A5500																											
Description	Spacing (mm)	Part no.																											
Mounting plate	0	173H7100																											
Angled spacer	-5°	171A5500																											